Europcar
my first rental

MAXI-COSI® Tobi

Gruppe 1, geeignet für Kinder von 9 Monaten bis ca. 3,5 Jahren (9-18kg)

1. DEN MAXI-COSI TOBI IM AUTO INSTALLIEREN



Beide Autogurt- Arretierungen an der Oberseite des Kindersitzes müssen geöffnet sein

Maxi-Cosi Tobi in Fahrtrichtung auf den Autositz stellen



- Beckengurt unter der Schalen muss über die roten Gurtmarkierungen laufen
- Autogurt mit dem Gurtschloss des Autos befestigen



Möglicherweise ist das Schlossteil des Autogurts zu lang ist:
- Das Autogurtschloss liegt dann über dem Fuß des Maxi-Cosi Tobi
- Der Sitz lässt sich dann nicht richtig befestigen
- Wählen Sie einen anderen Sitz im Auto



Den Schultergurt an der Seite, an der sich das Gurtschloss des Autos befindet, durch den roten Gurtschlitz auf der Rückenlehne ziehen



- Schulterteil entlang der roten Markierung für den Schultergurt an der Rückseite des Kindersitzes ziehen (6.1)
- Dann entlang der roten Markierung wieder nach außen ziehen (6.2)



Maxi-Cosi Tobi fest in den Sitz drücken (7.1) und Schultergurt gleichzeitig fest an ziehen (7.2)



- Erst Gurtarretierung an der Gurtschlossseite schließen (A)
- Dann Gurtarretierung auf der anderen Seite, in Richtung Aufrollautomat/Autotür schließen (B)

Für darüber hinausgehende Informationen ziehen Sie bitte die ausführliche Gebrauchsanweisung des Herstellers zu Rate (entweder auf der Rückseite des Sitzes zu finden oder bei jeder Europcar Station zu bekommen).

2. IHR KIND IN DEN MAXI-COSI TOBI SETZEN



- Setzen Sie Ihr Kind aufrecht in den Maxi-Cosi Tobi und überprüfen Sie die Gurthöhe
- Die richtige Höhe der Schultergurte ist erreicht, wenn die Gurte etwas oberhalb der Schulter in der Schale verschwinden



- Schultergurte und Kopfstütze sind höhenverstellbar
- Bewegen Sie die Kopfstütze am Handgriff an der Oberseite gleichzeitig nach vorne und nach oben oder unten



Setzen Sie Ihr Kind aufrecht in den Sitz. Legen Sie die Schlossteile aufeinander und schieben Sie diese in das Gurtschloss bis ein deutliches "Klick" hörbar ist. Durch das Schließen des Schlosses wird das Gurtsystem blockiert. Wenn Sie die Gurte verlängern wollen, muss das Schloss geöffnet werden



Ziehen Sie nun das Hosenträgersystem straff: an dem Verstellband soweit ziehen (4.1), bis die Anzeige am Gurtschloss grün ist (4.2)



- Anzeige noch auf silber: Gurt strammer anziehen
- Anzeige muss beim Wegfahren grün anzeigen
- Sitzt das Hosenträgersystem zu locker, obwohl die Anzeige auf grün steht: Gurt noch strammer anziehen
- Anzeige springt bei Bewegungen Ihres Kindes wieder auf silber: das ist normal und ohne Konsequenzen für die Sicherheit

Darüber hinausgehende Hinweise entnehmen Sie bitte der Originalgebrauchsanweisung des Herstellers (entweder an der Rückseite des Sitzes zu finden oder bei jeder Europcar Station zu bekommen).

WICHTIG

Der richtige Verlauf des Autogurts ist von höchster Wichtigkeit für die Sicherheit Ihres Kindes. Der Autogurt muss entlang der roten Markierungen an dem Maxi-Cosi Tobi montiert werden. Achten Sie darauf, dass die Gurte nicht verdreht sind oder doppelt liegen. Der Maxi-Cosi Tobi darf sowohl auf dem Beifahrersitz als auch auf dem Rücksitz benutzt werden. Auch wenn ein Airbag vorhanden ist. Wir empfehlen Ihnen jedoch, den Kindersitz auf dem Rücksitz zu montieren. Sollte dies nicht möglich sein, und Ihr Auto mit einem Airbag ausgestattet sein, stellen Sie den Vordersitz in die hinterste Position. Der Kindersitz muss immer mit dem Autogurt befestigt sein, auch wenn er nicht benutzt wird. Bei einer starken Bremsung kann ein nichtbefestigter Kindersitz Mitfahrer verletzen.

9360-3 11/09

Europcar

my first rental

MAXI-COSI Tobi

Group 1, Suitable for children from 9 months until 3,5 years (9-18kg)

1. INSTALLING THE MAXI-COSI TOBI IN YOUR CAR



1

Make sure that both seat belt clamps are open

Place the Maxi-Cosi Tobi on the car seat in a forward facing position

2



3

- The lap belt has to pass under the shell, over the red belt marks (3.1).
- Click the seat belt into the belt buckle of the car (3.2)



4

The buckle part of the seat belt may be to long:

- So the buckle protrudes above the frame of the Maxi-Cosi Tobi
- The Maxi-Cosi Tobi cannot be secured properly
- Choose another position in the car



5

Slide the shoulder part of the seat belt, on the side where the belt buckle of the car is also located, through the red belt slot on the backrest



6

- Pass the shoulder part along the red marks for the shoulder belt on the back of the Maxi-Cosi Tobi (6.1)
- Slide this through the second red belt slot outside (6.2)



7

Push the Maxi-Cosi Tobi firmly into the car seat (7.1) while at the same time pulling the shoulder belt tight (7.2)



8

- First shut the belt clamp on the belt buckle side (A)
- Then shut the belt clamp on the other side, in the direction of the roll-up mechanism (B)

For further information, please carefully read the manufacturer's detailed instruction manual. This can be found the storage compartment of your seat or you can ask for it at every Europcar station.

2. PLACING YOUR CHILD IN THE MAXI-COSI TOBI



1

- Place the child with straight back in the seat and check the belt height
- The height of the shoulder belt is correct when the belt disappears into the shell slightly above you child's shoulders



2

- Adjust the height of the shoulder belts in combination with and by means of the headrest
- Move the headrest by the handle on the top at the same time forwards and up or down



3

Place the child with his/ her back straight in the Maxi-Cosi Tobi. Slide the buckle sections together and insert them into the belt buckle with a clearly audible click. When the buckle is closed, the belt system is blocked and can only be pulled tighter. If you need to make the belts longer, the buckle must first be opened again



4

Now pull the harness system tight by pulling on the adjustment belt (4.1). Pull until the indicator on the belt buckle turns green (4.2)



5

If the indicator is still silver the belt should be pulled tighter. Make sure that the indicator is green before driving. If it seems like the harness belt is still loose even though the indicator is on green, the belt can be pulled more tightly. This will ensure optimum safety. While driving, it is possible that the indicator reverts back to silver as a result if the child's movements. This is normal and will not affect the child's safety.

For further information please carefully read the manufacturer's original instruction manual. This can be found at the backside of your seat or you can ask for it at every Europcar station.

IMPORTANT

- Make sure that the belts are not twisted or folded double
- Always use the belt pads, as they are essential for your child's safety. The textured side always has to be positioned properly on your child's chest/ shoulders
- The Maxi-Cosi Tobi may be used in the front seat and in the back seat. Even if the car is equipped with an airbag. However, we recommend installing it on the back seat. If this is not possible, make sure that, if installing on a front seat equipped with an airbag, the seat is in the rearmost position
- The seat must always be secured with the seat belt, even when not in use. A loose seat could injure other passengers in an emergency stop